




PC 5T Ceiling Loudspeaker




Cut out Ø 170 mm hole for PC 5T.



Connect speaker to signal line via block terminal.



Remove the front grill.



Carefully push speaker in the cut hole and fix the loudspeaker with mounting screws. Mount the grill on the loudspeaker.

COLOR

Black

Red

Yellow

Green

White

SP 10

COM

1.5 W

2.5 W

5 W

10 W