

HQ 15/HQ 30 horn loudspeakers

Package contains:

Loudspeaker 1pcs. Bracket 1pcs.



Remove mounting bracket from horn loudspeaker.


② HQ 15 HQ 30

Fix mounting bracket on the flat surface.



	COLOR	HQ 15	HQ 30
	Black	СОМ	СОМ
	White	15 W	30 W
	Green	7.5 W	15 W

Connect speaker to signal line via block terminal. (Select desired power from table)



Place loudspeaker in mounting bracket.

Please pay attention: Mount the loudspeaker on the reliable base only.